


128
GENERAL
MIDI
TONES

CTK-650

ELECTRONIC MUSICAL INSTRUMENT
INSTRUMENTO MUSICAL ELECTRONICO

OPERATION MANUAL (ENGLISH)




NOTE: This document includes the English sections from the original English/Spanish multi-language printed manual.

CASIO®

Control Locations

(E-2)





- ① 128 RHYTHMS list
- ② 32 PAD VARIATIONS list
- ③ START/STOP button
- ④ TEMPO indicator
- ⑤ TEMPO buttons
- ⑥ TRANPOSE/TUNING button
- ⑦ MIDI button
- ⑧ MULTI FUNCTION DISPLAY
- ⑨ RHYTHM button
- ⑩ TONE button
- ⑪ MAGICAL PRESET button
- ⑫ SPLIT button
- ⑬ LAYER button
- ⑭ 128 TONES list
- ⑮ 128 MAGICAL PRESETS list
- ⑯ 10 DIGITAL EFFECTS list
- ⑰ POWER indicator
- ⑱ POWER button
- ⑲ MODE button
- ⑳ VOLUME slider
- ㉑ SOUND/CONTROL PAD
- ㉒ INTRO button
- ㉓ NORMAL/FILL-IN button
- ㉔ VARIation/FILL-IN button
- ㉕ SYNCHRO/ENDING button
- ㉖ SONG MEMORY button
- ㉗ ACCOMP VOLUME button
- ㉘ 10-key/+/- pads
- ㉙ REGISTRATION button
- ㉚ DIGITAL EFFECT button
- ㉛ DEMO button
- ㉜ TOUCH RESPONSE button
- ㉝ MIDI terminals
For connection of other MIDI instruments and devices.
- ㉞ ASSIGNABLE jack
For connection of an optional sustain pedal (SP-2/SP-10).
- ㉟ PHONES/OUTPUT jack
For connection of commercially available headphones. Output from the speakers is automatically cut when headphones are connected.
- ㊱ DC 9V jack
For connection of an optional AC adaptor AD-5

Welcome...

To the happy family of satisfied CASIO electronic musical instrument owners! To get the most out of the many features and functions of the CTK-650, be sure to carefully read this manual and keep it on hand for future reference.

Important!

When using batteries, be sure to replace them or shift to one of the alternate power sources whenever you notice any of the following symptoms.

- Dim power supply indicator
- Abnormally low speaker/headphone volume
- Distortion of sound output
- A totally different tone may sound
- Abnormal rhythm pattern and demo tune play
- Continued sound output even after you release a button
- Occasional interruption of sound when playing at high volumes
- Sudden power failure when playing at high volumes

GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A (not applicable to other areas).

NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Main Features

- ☐ **128 amazingly realistic tones**
- ☐ **Layer and Split Keyboard capabilities for play of two tones at the same time**
 - **Layer Function**
Play two tones at the same time.
 - **Split Function**
Split the keyboard between two different tones.
- ☐ **Magical Preset for a new dimension in keyboard play**
 - Perform such “magical” functions as changing the tone each time you press a key, play a different chord each time you press a key, play tones along with percussion sounds, and more!
- ☐ **Sound/Control pads**
 - Choose from among 32 different set-ups.
 - Set up to play percussion sounds.
 - Set up for subtle control over tones played on the keyboard.
- ☐ **Enhanced auto-accompaniment function for greater versatility**
 - 128 built in auto-accompaniment patterns.
 - Combine different rhythms to create your own patterns.
 - Full-Range Chords allow both chord and melody play across the entire keyboard range.
- ☐ **Song Memory**
 - You can store up to 1,300 notes for later playback.
- ☐ **Touch Response**
 - Automatic adjustment of output to match keyboard pressure.
- ☐ **Transpose Function**
 - An easy operation instantly changes the key of the keyboard.
- ☐ **10 versatile digital effects**
 - Choose from various reverb effects or even an rotating speaker effect.
- ☐ **MIDI compatible**
 - Hook up to other MIDI devices and expand your creative potential.
- ☐ **Registration Memory**
 - Store up to four set-ups for instant recall when you need them.

Contents

Control Locations	E-2
Quick Reference	E-7
To switch power on and off	E-7
To change tones	E-7
To switch Touch Response on and off	E-7
To play the demo tunes	E-7
Using effects	E-7
To select an effect	E-7
To switch effects on and off	E-7
To select and play a rhythm	E-7
Using auto-accompaniment	E-8
To play a CASIO CHORD auto-accompaniment	E-8
To play a FINGERED auto-accompaniment	E-8
To start an accompaniment with synchro start	E-8
Adjusting the accompaniment volume	E-9
To adjust the accompaniment volume	E-9
Using the sound/control pads	E-9
To play a pad	E-9
To change the pad functions	E-9
Using the Song Memory	E-9
To record to Song Memory	E-9
To play back a song from Song Memory	E-9
To tune the keyboard	E-10
To transpose the keyboard	E-10
To set the touch sensitivity	E-10
 Part 1 Before using the keyboard	 E-11
About the power supply	E-11
Installing the batteries	E-11
Using AC power	E-12
Using a car's cigarette lighter	E-12
Auto Power Off Function	E-12
To cancel the Auto Power Off function	E-13
About settings and memory contents	E-13
General overview of CTK-650 operation	E-14
How the display shows data	E-14
About CTK-650 modes	E-14
 Part 2 Basic operations	 E-16
To switch power on and off	E-16
To change tones	E-16
Digital Sampling	E-17
Polyphony	E-17
Touch Response	E-17
To switch Touch Response on and off	E-17
Playing the demo tunes	E-18

To start demo tune play	E-18
To stop demo tune play	E-18
Using effects	E-18
Types of effects	E-19
To select an effect	E-19
To switch effects on and off	E-20
Playing rhythms	E-20
To select and play a rhythm	E-20
Improvising with the preset patterns	E-21
To play intro and ending patterns	E-22
Using auto-accompaniment	E-22
About the accompaniment keyboard	E-22
Using the CASIO CHORD system	E-23
To play a CASIO CHORD auto-accompaniment	E-24
Using standard fingerings	E-24
To play a FINGERED auto-accompaniment	E-25
To start an accompaniment with synchro start	E-26
Improvising with the preset accompaniment patterns	E-26
Using Full-Range Chords	E-26
To play a FULL-RANGE CHORD auto-accompaniment	E-26
Example - To play the chord C major	E-27
Adjusting the accompaniment volume	E-27
To adjust the accompaniment volume	E-27

Part 3 Advanced Operations E-28

Using the Split function	E-28
To split the keyboard	E-28
To change the location of the split point	E-29
To unsplit the keyboard	E-29
Using the Layer function	E-29
To layer tones	E-29
To unlayer the keyboard	E-30
Using Split and Layer together	E-30
To split and layer the keyboard	E-31
Using the sound/control pads	E-32
Types of operations available for the pads	E-32
To change the pad functions	E-32
Assigning rhythms to the Intro, Variation, and Ending Buttons	E-34
To change the Intro, Fill-In, and Ending button rhythm assignments	E-35
Using Magical Presets	E-35
To change the Magical Preset	E-35
To switch Magical Preset off	E-36
About Magical Presets	E-36
Break Beat Application Examples	E-36
To start a Free Session progression	E-37
Using tone buttons with Magical Presets	E-38
To change the tone	E-38
Using the Registration function	E-39
To store a set-up	E-39
To recall a setup	E-40
To switch the Registration function off	E-41
Assignable jack	E-41

To change the assignable jack function	E-42
Using the Song Memory	E-43
Basic Song Memory operations	E-43
To record to Song Memory	E-44
To play back a song from Song Memory	E-44
About data recorded in the Song Memory	E-45
How Touch Response is handled by Song Memory	E-45
Part 4 MIDI	E-46
What is MIDI?	E-46
What the MIDI Mode allows you to do	E-46
Send	E-46
Receive	E-46
About the MIDI terminals	E-46
MIDI IN	E-47
MIDI OUT	E-47
What is a MIDI channel?	E-47
To set the basic channel	E-48
MIDI Send Channel Allocation	E-48
Volume balance between channels	E-50
Modulation depth, stereo position (pan), effect volume (effect send)	E-50
Song Memory and demo tunes	E-50
General MIDI	E-51
To switch General MIDI on and off	E-51
Local control settings	E-52
To switch Local Control on and off	E-52
Bend range settings	E-53
To set the bend range	E-53
Accompaniment data	E-53
To switch accompaniment data output on and off	E-53
Assignable jack data	E-55
Specifying a tone for each receive channel	E-55
To specify a tone for a receive channel	E-55
MIDI Receive Channel Allocation	E-56
Part 5 Other Settings	E-57
To tune the keyboard	E-57
To transpose the keyboard	E-58
To set the touch sensitivity	E-59
Part 6 Technical Reference	E-60
Troubleshooting	E-60
Precautions	E-61
Specifications	E-61
Part 7 Appendix/Apéndice	A-1
Fingered Chord Charts	A-1
Melodycomp Chord Charts	A-4
Free Session Chord Progression Charts: Key of C	A-4
Note Table	A-6

Quick Reference

This part of the manual provides a brief overview of keyboard operation. This is meant for experienced users, so be sure to read the rest of the manual for details before trying to actually use the keyboard.

■ To switch power on and off (Page E-16)



Press the POWER button to switch power on and off.

■ To change tones (Page E-16)



1. Press the TONE button.



2. Use the 10-key pad to input the 3-digit number that identifies the tone you want to select.

■ To switch Touch Response on and off (Page E-17)



Press the TOUCH RESPONSE button to switch Touch Response on and off.

■ To play the demo tunes (Page E-18)



Press the DEMO button to start and stop demo tune play.

■ Using effects (Page E-18)

To select an effect



1. Press the DIGITAL EFFECT button to switch digital effects on.

2. Use the 10-key pad to input the number for the effect you want to use.

To switch effects on and off



Press the DIGITAL EFFECT button to switch the currently selected effect on and off.

■ To select and play a rhythm (page E-20)



1. Use the MODE button to enter the NORMAL mode (all MODE indicators unlit).



2. Press the RHYTHM button.



START/STOP



START/STOP



3. Use the 10-key pad to input the 3-digit rhythm number for the rhythm you want to use.
4. Press the START/STOP button to start play of the rhythm.
5. To stop rhythm play, press the START/STOP button again.

■ Using auto-accompaniment (page E-22)

To play a CASIO CHORD auto-accompaniment

FULL-RANGE
CHORD ○

FINGERED ○

CASIO
CHORD ●

MODE



1. Use the MODE button to select CASIO CHORD.
2. Select an auto-rhythm.
3. Start play of the rhythm.
4. Press either one or up to four keys on the accompaniment keyboard (page E-23), and the corresponding accompaniment starts to play automatically.
5. Continue pressing different keys on the accompaniment keyboard.
6. To stop auto-accompaniment play, press START/STOP again.

START/STOP



To play a FINGERED auto-accompaniment

FULL-RANGE
CHORD ○

FINGERED ●

CASIO
CHORD ○

MODE



1. Use the MODE button to select FINGERED.
2. Select an auto-rhythm.
3. Start play of the rhythm.
4. Play a chord on the accompaniment keyboard (lower 1.5 octaves) to start play of the auto-accompaniment.
5. Continue pressing keys on the accompaniment keyboard.
6. To stop auto-accompaniment play, press START/STOP again.

START/STOP



To start an accompaniment with synchro start

MODE



SYNCHRO/
ENDING



1. Use the MODE button to select either CASIO CHORD or FINGERED.
2. Select a rhythm.
3. Press the SYNCHRO/ENDING button. At this time, the indicator above the button lights.

4. Play a chord on the accompaniment keyboard.
5. To stop the accompaniment pattern, press START/STOP again.

■ Adjusting the accompaniment volume (Page E-27)

Use the following procedure to set the volume that the accompaniment is played. You can set the volume to any value in the range of 000 to 127.

To adjust the accompaniment volume


1. Press the ACCOMP VOLUME button.
2. Use the 10-key pad to input a 3-digit number and specify the accompaniment volume level.

■ Using the sound/control pads (Page E-32)

To play a pad

Simply press one of the four pads to play the sound assigned to it.

To change the pad functions

1. Press any one of the four pads and the number that identifies the set of functions currently assigned to the pads appears on the display. 
2. While the function set number is on the display, use the 10-key pad to input the number of the set of functions you want to change to.


■ Using the Song Memory (Page E-43)


To record to Song Memory

1. Set up the keyboard to play the tune you want to play.

SONG MEMORY



2. Press the SONG MEMORY button until the message  appears on the display.



3. Play the song that you want to perform.

START/STOP





4. After the song is finished, press the START/STOP button to stop the recording operation.

To play back a song from Song Memory

SONG MEMORY



1. Press the SONG MEMORY button until the message  appears on the display.



START/STOP



2. Press the START/STOP button to start playback.

■ To tune the keyboard (Page E-57)

TRANPOSE/
TUNE



1. Press the TRANPOSE/TUNE button until the message **t u n** appears on the display.



2. Use the 10-key pad's [+] and [-] buttons to tune the keyboard.

■ To transpose the keyboard (Page E-58)

TRANPOSE/
TUNE



1. Press the TRANPOSE/TUNE button until the message **t r n** appears on the display.



2. Use the 10-key pad's [+] and [-] buttons to select a key.

■ To set the touch sensitivity (Page E-59)

TOUCH RESPONSE



1. Press the TOUCH RESPONSE button.
2. Use the 10-key pad to input the number that identifies the touch sensitivity you want to use.

Part 1 Before using the keyboard

Be sure to read the contents of this part of the manual before using the keyboard for the first time.

■ About the power supply

You can power your keyboard with 6 D batteries, standard AC power (with an optional AC adaptor) or by plugging in to the cigarette lighter of a car (with an optional car adaptor).

Installing the batteries

This keyboard can be powered by 6 D size (SUM-1/R20P) manganese dry cell batteries. Make sure that the unit is turned off when installing batteries.

1. Open the battery compartment cover on the bottom of the unit.
2. Load new batteries as illustrated, taking care that the plus (+) and minus (-) poles are facing in the correct directions.
3. Replace the battery compartment cover.
 - Standard battery life is approximately 5 hours (SUM-1).

Important!

Any of the following conditions indicates that battery power is low and that you should replace batteries or shift to one of alternate power sources as soon as possible.

- Dim power supply indicator
- Abnormally low speaker/headphone volume
- Distortion of sound output
- A totally different tone may sound
- Abnormal rhythm pattern and demo tune play
- Continued sound output even after you release a button
- Occasional interruption of sound when playing at high volume
- Sudden power failure when playing at high volumes

Precautions

Incorrectly using batteries can cause them to leak or burst, and may damage your unit. Note the following precautions:

- Be sure that the plus (+) and minus (-) poles are facing in the correct directions.
- Do not mix battery types.
- Do not mix new batteries with old ones.
- Never leave dead batteries in the battery compartment.
- Remove batteries when not using the unit for extended periods.
- Never try to recharge the batteries that are specified for the power supply of this unit.
- Do not expose batteries to direct heat, let them become shorted or try to take them apart.


(If a battery leaks, clean out the battery compartment of the unit immediately, taking care to avoid letting the battery fluid come into direct contact with your skin.)

Using AC power

An AC adaptor (AD-5, optional) is required when using household current. Use only genuine CASIO adaptor with the same voltage rating (100, 117, 220 or 240V) as the power supply in your area to prevent damage to internal components. Be sure to turn the power of the unit off before you connect the adaptor to the unit. Plug the AC adaptor into the AC outlet and the cord into the unit. This will automatically cut off the battery power supply.

Using a car's cigarette lighter

With the car adaptor (CA-5, optional), DC power is supplied from a car battery through the cigarette lighter. Be sure to turn the power of the unit off before you connect the adaptor to the unit.



Important!

- The adaptor may become warm when it is being used. This is normal and does not indicate any problem.
- Be sure to unplug the adaptor from the power source when you are not using the unit.
- Whenever connecting or disconnecting the adaptor, be sure that the power of the unit is switched off.
- Be sure to unplug the car adaptor from the cigarette lighter socket when you are not using the unit. Leaving the car adaptor plugged in can cause damage or can run down your car's battery.
- Never connect the car adaptor to a 24V DC cigarette lighter (in a bus or truck). Doing so can damage the unit.
- Certain makers of cars may have non-standard cigarette lighter shapes or sizes. Be sure to check the size of your car's cigarette lighter before using the car adaptor.
- Never use a power supply that does not match that specified for the unit. Doing so can damage the adaptor or your unit.

Auto Power Off Function

The Auto Power Off function automatically switches power off if you do not perform any operation for about six minutes. You can also use the following operation to cancel the Auto Power Off function so that it does not switch power off.

To cancel the Auto Power Off function

While holding down the TONE button, switch power on.

- The Auto Power Off function remains cancelled until you manually switch power off.

About settings and memory contents

- Whenever power is switched off by pressing the POWER button or by operation of the Auto Power Off function, tone and rhythm settings, Song Memory contents (page E-43), and Registration Memory contents (page E-39) are retained. All of these settings and memory data items are available when you switch power on again.
- The settings and data described above are retained while power is switched off as long as electrical power is supplied to the unit. This means that if you remove batteries or if batteries go dead, and you disconnect the unit from an external power supply (AC adaptor or car adaptor), settings and data stored in memory will all be lost.
- Note that the following settings are not retained when power is switched off, and they are initialized whenever you switch power on.







Setting	Initialized Default
Displayed Number	Tone number
Transpose	0
Tuning	00
Split Point	060 (B2/C3)
Local Control On/Off	On

■ General overview of CTK-650 operation

This section provides a general overview of main CTK-650 operations. It mainly focuses on how the display shows data and how to change between different modes. Be sure to read this section before using the keyboard for the first time.

How the display shows data

The 3-digit display is used to show a variety of numeric data and other indicators. An indicator on the display also tells you what kind of data is currently displayed.

Sample Display	Indicator Meaning
	Tone number display
	Rhythm number display (standard)
	Rhythm number display (for rhythm assigned to INTRO, NORMAL/FILL-IN, VAR/FILL-IN, or SYNCHRO/ENDING buttons). This display appears only when you press INTRO, NORMAL/FILL-IN, VAR/FILL-IN or SYNCHRO/ENDING, to identify the number of the rhythm assigned to the button. After a few seconds the display returns to the normal rhythm display.
	Magical Preset number display
	Demo tune number
	Pad function number display (appears for about one second after the pad is pressed)

About CTK-650 modes

With the CTK-650, you must enter various modes in order to perform certain operations. This section describes the main modes of the CTK-650.

Button	Mode	Description
MODE	NORMAL	The keyboard plays like a standard piano or organ. This mode is selected when all the MODE indicators are unlit.

Button	Mode	Description
MODE	CASIO CHORD	You can use the auto-accompaniment functions described on page E-23.
	FINGERED	You can finger chords as you normally do, and have the accompaniment pattern follow along with you (page E-25).
	FULL-RANGE CHORD	You can use the entire range of the keyboard for FINGERED play and melody play (page E-26).
MAGICAL PRESET	MAGICAL PRESET	Use this mode to select the Magical Preset function you want to use (page E-35).
DEMO	DEMO	Use this mode to play the demo tunes (page E-18).
SONG MEMORY	SONG MEMORY	Use this mode to record songs to and play songs back from memory (page E-43).
MIDI	MIDI	This mode lets you set up the keyboard to exchange data with another MIDI device (page E-46).
SPLIT	SPLIT	Use this mode to split the keyboard between two different tones (page E-28).
LAYER	LAYER	Use this mode to assign two different tones to each keyboard key (page E-29).
DIGITAL EFFECT	DIGITAL EFFECT	Use this mode to select the digital effect you want to use (page E-18).

Part 2 Basic operations


This part of the manual provides you with the basic information you need to use your keyboard.

■ To switch power on and off

1. Press the POWER button to switch power on. The indicator above the button is lit while power is on.



2. Adjust the volume.



- Be sure to adjust the volume to a relatively low setting before playing the keyboard.

3. Press the keyboard keys.

- Adjust the volume to the level you want while playing the keyboard.
- Whenever you switch power on, the tone that was selected when you last switched power off is still selected.

4. To switch power off, press the POWER button again.



■ To change tones


1. Look at the tone list printed on the keyboard's console and find the one you want.
 - A total of 128 tones are available.

2. Press the TONE button.



- The number for the tone that is currently selected is shown on the display.

3. Use the 10-key pad to input the 3-digit number that identifies the tone you want to select.



- Use the numeric buttons to input a 3-digit number.
- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed tone number by 1, while [-] decreases it.
- Be sure to always specify a 3-digit number.
- If you specify a number greater than 127, tone number 127 is selected automatically.
- If you discover a mistake before you input the third digit, press the TONE button to return to the previously set tone number.
- With tone number 031 (GT HARMONICS), the high octave from C#5 to C6 is identical to the high octave from C#4 to C5.

Digital Sampling

A number of the tones that are available with this keyboard have been recorded and processed using a technique called digital sampling. To ensure a high level of tonal quality, samples are taken in the low, mid, and high ranges and then combined to provide you with sounds that are amazingly close to the originals. You may notice very slight differences in volume or sound quality for some tones when you play them at different positions on the keyboard. This is an unavoidable result of multiple sampling, and it is not a sign of malfunction.

Polyphony


The term polyphony refers to the maximum number of notes you can play at the same time. The CTK-650 has 32-note polyphony, which includes the notes you play as well as the rhythms and auto-accompaniment patterns that are played by the keyboard. This means that when a rhythm or auto-accompaniment pattern is being played by the keyboard, the number of notes (polyphony) available for keyboard play is reduced. Also note that some of the tones offer only 16-note polyphony.

■ Touch Response

Touch Response makes it possible for the keyboard to match the power of the note produced with the amount of pressure you use to press the keyboard keys. Note that beginners or those with insufficient strength in their fingers can use the procedure to switch Touch Response off.

To switch Touch Response on and off

Press the TOUCH RESPONSE button to switch Touch Response on and off.



- When Touch Response is switched off, the notes produced by the keyboard are not affected by the keyboard pressure.
- Touch Response is on when the TOUCH RESPONSE indicator is lit.
- Note that when you switch power on, the Touch Response on/off setting is the one that was selected when you last switched power off.
- Touch Response is not applied to the accompaniment keyboard when you are using auto-accompaniment (page E-22). It is, however, applied to the melody keyboard.
- The TOUCH RESPONSE button is automatically deactivated whenever a demonstration tune is playing. If Touch Response is switched on when you start play of the demo tune, it remains on and cannot be switched off during demo tune play. If it is switched off when you start play of the demo tune, it remains off.
- You can also adjust the Touch Response sensitivity using the procedures described on page E-59.

■ Playing the demo tunes

This keyboard comes with the following three pre-recorded demo tunes that you can use for practice or simply for your listening enjoyment.

Tune Number	Name	Composer	Play Time
0	Cosmopolitan X-Cursion	(CASIO original)	2:04
1	Lightin' Up	Edward Alstrom	2:43
2	Connect The Dots	Edward Alstrom	2:32

- Note that you cannot start playback of a demo tune while you are recording to Song Memory (page E-43).

To start demo tune play

1. Switch power on and adjust the volume level.
2. Press the DEMO button.



- Demo tune play continues in a sequential endless loop until you switch it off.
- The number of the demo tune currently playing is shown on the display.
- You can play along on the keyboard while a demo tune is playing back.

3. You can change the demo tune being played by pressing [+] (to advance) or [-] (to move back) in the 10-key pad.



To stop demo tune play

Press the DEMO button again to stop Demo tune play.



■ Using effects

A total of 10 digital effects can be applied to the keyboard's tone to create exactly the mood that you want for your music. Note that only one effect can be selected at a time.

Types of effects

Effect	Effect Number	Description
REVERB 1	$E - 0$	Deep reverb
REVERB 2	$E - 1$	Medium reverb
REVERB 3	$E - 2$	Shallow reverb
CHORUS	$E - 3$	Adds depth and breadth to sound. Recommended for electric piano.
TREMOLO	$E - 4$	Causes pulsating sound. Recommended for electric piano or vibraphone.
PHASE SHIFTER	$E - 5$	Rotating effect
ORGAN SP	$E - 6$	Like a rotating speaker on an electronic organ. Recommended for organ tones.
ENHANCER	$E - 7$	Strong attack effect
FLANGER	$E - 8$	Adds depth and sharpness. Recommended for bass sounds.
EQ LOUDNESS	$E - 9$	Enhances low range.


- Digital effects are applied to notes played on the keyboard, pad sounds, rhythms, and auto-accompaniments
- Effects $E - 3$ through $E - 8$ are quite strong, and may cause problems for the tone you are trying to play. When this happens, try changing to effects $E - 0$ through $E - 2$.
- Depending on the tone and rhythm you are using, the EQ LOUDNESS effect may cause distortion at high volume settings. When this happens, try lowering the volume.

To select an effect


1. Press the DIGITAL EFFECT button to switch digital effects on.




- When you do, the DIGITAL EFFECT indicator lights.
- The number that appears on the display indicates the currently selected rhythm.



2. Use the 10-key pad to input the 1-digit number for the effect you want to use. To select REVERB 1, for example, input 0.



- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed effect number by 1, while [-] decreases it.




- Preset effects are automatically selected whenever you play a demo tune. These presets cannot be changed or switched off during demo tune play.
- If you change the effect while a note is still sounding, the keyboard may make an irregular sound when the effect change is made.

To switch effects on and off



Press the DIGITAL EFFECT button to switch the currently selected effect on and off.



■ Playing rhythms


This keyboard features a collection of 128 exciting built-in rhythm patterns. Each pattern provides percussion back up for all your performances.

To select and play a rhythm

1. Make sure that power is switched on and that volume is adjusted to a comfortable level.
2. Use the MODE button to enter the NORMAL mode (all MODE indicators unlit).



- Each time you press the MODE button, the status of the indicators changes as illustrated here.




3. Look at the rhythm list printed on the keyboard's console and find the one you want.
4. Press the RHYTHM button.



- When you do, the RHYTHM indicator lights.
- The number that appears on the display indicates the currently selected rhythm.




5. Use the 10-key pad to input the 3-digit rhythm number for the rhythm you want to use. To select "012 8 BEAT 2", for example, input 0, 1, 2.



- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed rhythm number by 1, while [-] decreases it.

Be sure to always specify a 3-digit number.



- If you specify a number greater than 127, rhythm number 127 is selected automatically.
- If you discover a mistake before you input the third digit, press the RHYTHM button to return to the previously set rhythm number.

6. Press the START/STOP button to start play of the rhythm.




- When you do, the selected rhythm starts to sound, with the indicator next to the START/STOP button flashes with each beat.

7. Use the TEMPO buttons to adjust the tempo of the rhythm.




- When you press one of the TEMPO buttons, the tempo setting appears on the display. The value indicates the number of beats per minute. The display returns to normal shortly after you release the TEMPO button.

- Each time you press one of the TEMPO buttons while the tempo value is displayed, the tempo setting changes one step, within the range of 40 to 255.



- Holding down either of the TEMPO buttons changes the tempo setting at high speed.



- To reset the tempo to the standard value of each rhythm, press both TEMPO buttons or the 10-key pad's [+] and [-] buttons at the same time.

- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed rhythm number by 1, while [-] decreases it. Be sure to always specify a 3-digit number.

8. To stop rhythm play, press the START/STOP button again.



■ Improvising with the preset patterns

Pressing the START/STOP button to start rhythm play causes the normal version of the pattern to be played. You can also play a variation of the rhythm using the operation described below.




Important!

- In addition to the variations described below, you can also assign specific rhythm types to each of INTRO, NORMAL/FILL-IN, VAR/FILL-IN, and SYNCHRO/ENDING buttons. See page E-34 for details.






- Press this button while the normal rhythm pattern is playing in order to switch to the variation pattern.
- If you press this button while the variation pattern is playing, a one-measure fill-in pattern is played and then play of variation pattern continues.

<p>NORMAL/ FILL-IN</p> 	<ul style="list-style-type: none"> • Press this button while the variation rhythm pattern is playing in order to switch to the normal pattern. • If you press this button while the normal pattern is playing, a one-measure fill-in pattern is played and then play of normal pattern continues.
--	---

- Note that fill-in patterns can logically be inserted at specific locations inside a chord progression. Because of this, the fill-in pattern may not sound immediately when you press a fill-in button. Instead, it will sound at the next location that a fill-in pattern is possible.
- The fill-in patterns for rhythms 017 and 047 are two measures long. All others are one measure long.

To play intro and ending patterns

<p>INTRO</p>  <p>VAR/ FILL-IN</p> 	<ul style="list-style-type: none"> • When no rhythm is playing, press the INTRO button instead of the START/STOP button. When you do, an intro pattern is played to start the normal version of the selected rhythm pattern. • To start play of the variation pattern, press INTRO and then VAR/FILL-IN.
<p>SYNCHRO/ ENDING</p> 	<ul style="list-style-type: none"> • While a rhythm is playing, pressing SYNCHRO/ENDING instead of START/STOP plays an ending pattern, after which play of the pattern stops.


■ Using auto-accompaniment

This keyboard features 128 accompaniment patterns that let you add full accompaniments to your performances automatically. With auto-accompaniment, part of the keyboard is reserved as an accompaniment keyboard. As you play your chords on the accompaniment keyboard, the accompaniment patterns adjusts automatically to follow the progression you play.

You get a choice between two different methods for chord play. FINGERED lets you play chords as you normally do, while CASIO CHORD makes it possible to play fully formed chords with one finger. Note that this keyboard also features a FULL RANGE CHORD system (page E-26) that lets you use the entire keyboard for chord and melody play.





About the accompaniment keyboard

The lower (left) 1.5 octaves are reserved for use as an accompaniment keyboard whenever you select CASIO CHORD or FINGERED with the MODE button. The panel above the accompaniment keyboard keys is marked with the names of the notes they play. The remainder of the keyboard (the part that is not included in the accompaniment keyboard) is called the melody keyboard. Please be sure to remember these terms, because they will be used throughout the rest of this manual.



Using the CASIO CHORD system

The CASIO CHORD system lets you easily play the four main types of chords. Play of chords is simplified as shown in the chart below.


Keys	Chord Type	Example
Pressing one accompaniment key	Major chord	C (C Major Chord) 
Pressing two accompaniment keys	Minor chord	Cm (C Minor Chord) 
Pressing three accompaniment keys	Seventh chord	C7 (C Seventh Chord) 
Pressing four accompaniment keys	Minor seventh chord	Cm7 (C Minor Seventh Chord) 

Note

- The bottom (leftmost) note that you play determines the name of the chord. If the bottom note is a C for example, the keyboard produces a C chord.


To play a CASIO CHORD auto-accompaniment

1. Use the MODE button to select CASIO CHORD.



2. Select an auto-rhythm as described under "To select and play a rhythm" on page E-20.

3. Start play of the rhythm.



- If you want start play of the normal rhythm pattern, press START/STOP.
- To start play of the variation rhythm pattern, press VAR/FILL-IN.
- You can also use synchro start (page E-26) to start rhythm play.


4. Press either one or up to four keys on the accompaniment keyboard, and the corresponding accompaniment starts to play automatically.
5. Continue pressing different keys on the accompaniment keyboard to play your chord progression.
6. To stop auto-accompaniment play, press START/STOP again.



Using standard fingerings

The FINGERED mode lets you play a wider variety of chords. In this mode, you can start play of an accompaniment pattern by pressing three or four of the accompaniment keyboard keys.

This keyboard is capable of recognizing 14 different chords. The following shows the fingerings of these chords with a root of C. Note that you can omit the fifth notes (which are shown inside parentheses in the illustrations below) to produce 7, m7, maj7, add9 and mM7 chords.



*1 With this chords, the lowest note in your fingering is always used as the root.

Make sure that your fingering correctly identifies the root you want to use.

Important!

- If you play one or two notes only in the left hand, or three notes that do not make up a recognizable chord formation (for example, C-D-D[#]), no sound will be produced. FINGERED MODE requires a conventional three or four-note chord formation to produce an auto-accompaniment. Also, note that auto-chords only work in conjunction with rhythm patterns, and not independently of them.

Notes


- The above examples show only one of the possible fingerings for each chord. Note that you can play the notes that form a chord in any combination. Each of the following fingerings for example, produces the same C chord.



- See the “List of fingered chords” on page A-1 for information on the fingerings of chords for all roots.


To play a FINGERED auto-accompaniment

1. Use the MODE button to select FINGERED.



2. Select an auto-rhythm as described under “To select and play a rhythm” on page E-20.

3. Start play of the rhythm.



- If you want start play of the normal rhythm pattern, press START/STOP.
- To start play of the variation rhythm pattern, press VAR/FILL-IN.
- You can also use synchro start (page E-26) to start rhythm play.

4. Play a chord on the accompaniment keyboard to start play of the auto-accompaniment.
5. Continue pressing keys on the accompaniment keyboard to play your chord progression.
6. To stop auto-accompaniment play, press START/STOP again.



To start an accompaniment with synchro start

1. Use the MODE button to select either CASIO CHORD or FINGERED.



2. Select a rhythm using the procedure described under “To select and play a rhythm” on page E-20.

3. Press the SYNCHRO/ENDING button. At this time the TEMPO indicator lights.



- If you want to start out with the variation pattern of the selected rhythm, press VAR/FILL-IN here.

4. Play a chord on the accompaniment keyboard and the accompaniment pattern starts to play.

5. To stop the accompaniment pattern, press START/STOP again.

Improvising with the preset accompaniment patterns

You can use intro, fill-in, variation, and ending operations (see “Improvising with the preset patterns” on page E-21) with auto-accompaniment. Note the following when using intro and ending patterns.

- When an intro pattern is playing, the final measure of the pattern is indicated by the tempo indicator speeding up. This signals you to get ready to start playing.
- Intro patterns are available in major chord and minor chord versions. The keyboard automatically selects the appropriate version in accordance with the chord you play to start the accompaniment pattern.
- Ending patterns are also available in major chord and minor chord versions. The keyboard automatically selects the correct version in accordance with the last chord you play at the end of the accompaniment.

Using Full-Range Chords

This function lets you use the entire range of the keyboard for play of accompaniment and melody. Unlike the FINGERED mode, the melody can be played in the accompaniment keyboard range, and chords can be played in the range of the melody keyboard.


To play a FULL-RANGE CHORD auto-accompaniment

1. Use the MODE button to select FULL-RANGE CHORD.



2. Select an auto-rhythm as described under “To select and play a rhythm” on page E-20.

3. Start play of the rhythm.




- If you want start play of the normal rhythm pattern, press START/STOP.
- To start play of the variation rhythm pattern, press VAR/FILL-IN.
- You can also use synchro start (page E-26) to start rhythm play.

4. Play the song on the keyboard.

- Anything you play using one or two keys at the same time is considered to be part of the melody, and so the corresponding notes sound as you play them.
- Anything you play using three or more keys at the same time is considered to be part of the accompaniment, and so the matching chord (using the same fingerings as FINGERED) is played.

Example - To play the chord C major

Any of the fingerings shown in the illustration below will produce C major.



- It makes no difference how far apart the keys you play are.
- As with the Fingered Mode (page E-24), you can play the notes that form a chord in any combination.
- It makes no difference if your fingering includes two or more of the same note.

■ Adjusting the accompaniment volume

Use the following procedure to set the volume that the accompaniment is played. You can set the volume to any value in the range of 000 to 127.

To adjust the accompaniment volume


1. Press the ACCOMP VOLUME button.
2. Use the 10-key pad to input a 3-digit number and specify the accompaniment volume level.
 - You can also use the [+] and [-] buttons. Pressing [+] increases the volume by 1, while [-] decreases it.
 - Holding down either of the +/- value buttons changes the displayed value at high speed.
 - Be sure to specify a 3-digit number.
 - If you specify a number greater than 127, an accompaniment volume of 127 is set automatically.
 - Remember that you have about five seconds after pressing the ACCOMP VOLUME button to input the first digit. Otherwise, the accompaniment number will disappear from the display, and you will have to press the ACCOMP VOLUME button again to get it back.
 - Pressing the [+] and [-] buttons at the same time automatically sets an accompaniment volume of 100.

Part 3 Advanced Operations

This part of the manual describes the more advanced features and functions of the CTK-650. Using these features effectively helps to add something extra to your performances.


■ Using the Split function

Split lets you assign two tones to different locations on the keyboard.




To split the keyboard

1. Select the tone that you want to assign to the high end of the keyboard.



- As an example, we will assign FLUTE (tone number 073) to the high end.




2. Press the [SPLIT] button to activate the Split function.




- When you do, the SPLIT indicator lights.
- The number that appears on the display indicates the tone currently assigned to the low end of the keyboard.



3. Select the tone that you want to assign to the low end of the keyboard.




- As an example, we will assign HARP, (tone number 046) to the low end.



The keyboard is now split in the center, at the point shown in the illustration above.

To change the location of the split point

1. Hold down the SPLIT button for about two seconds, and then press the keyboard key where you want the far left key of the high end to be.



- When you split the keyboard, the SPLIT indicator lights.
- When you hold down the SPLIT button, the first number that appears on the display indicates the current tone number. The next number that appears indicates the current split point location.
- After you press a keyboard key to specify a new split point, the first number that appears on the display indicates the new split point. The next number that appears indicates the current tone number.
- The 61 keys of the keyboard are numbered, left to right, from 036 to 096.



The keyboard is now split to the left of the keyboard key you pressed in the above procedure.

Important!

The split button cannot be used during play along with demo tunes or with tunes playing back from the Song Memory.

To unsplit the keyboard

Simply press the SPLIT button so that the SPLIT indicator goes out.




■ Using the Layer function


Layer makes it possible to play two different tones at the same time by pressing a single key.

To layer tones

1. Select the tone that you want to assign as the base tone.




- As an example, we will set STUDIO PIANO (tone number 002) as the base tone.



2. Press the LAYER button to activate the Layer function.





- When you do, the LAYER indicator lights.
- The number that appears on the display indicates the tone currently assigned as the layered tone.



3. Select the tone that you want to assign as the layered tone.



- As an example, we will assign SYNTH STRINGS 2, (tone number 051) as the layered tone.



Now when you play any keyboard key, both tones that you assigned in the above procedure sound.

Important!

The layer button cannot be used during play along with demo tunes or with tunes playing back from the Song Memory. Also note that layering causes a reduction in polyphony (to 8-, 10- or 16-note polyphony, depending on the tones that you layer).


To unlayer the keyboard

Simply press the LAYER button so that the LAYER indicator goes out.




■ Using Split and Layer together

You can also use Split and Layer in combination, which results in a split keyboard configuration where the layering for the high end of the keyboard is different from the layering at the low end, as shown in the illustration, below.




To split and layer the keyboard

1. First, check the SPLIT and LAYER indicators to make sure that they are off. If they aren't, press the SPLIT and LAYER buttons to switch them off.



2. Select the tone that you want to assign as the base tone for the high end of the keyboard.



- As an example, we will assign STUDIO PIANO (tone number 002) as the high end base tone.




3. Press the LAYER button to activate the Layer function.




- When you do, the LAYER indicator lights.

4. Select the tone that you want to assign as the layered tone for the high end of the keyboard.



- As an example, we will assign SYNTH STRINGS 2 (tone number 051) as the high end layered tone.



5. Press the LAYER button to deactivate the Layer function.




- When you do, the LAYER indicator goes out.

6. Press the SPLIT button to activate the Split function.




- When you do, the SPLIT indicator lights.

7. Select the tone that you want to assign as the base tone for the low end of the keyboard.



- As an example, we will assign SLAP BASS (tone number 036) as the low end base tone.



8. Press the LAYER button to activate the Layer function.





- When you do, the LAYER indicator lights.


9. Select the tone that you want to assign as the layered tone for the low end of the keyboard.



- As an example, we will assign GUNSHOT (tone number 127) as the low end layered tone.



The keyboard is now split and layered in the configuration illustrated below.



■ Using the sound/control pads

The sound/control pads put a variety of useful sound effects and controls at your fingertips. You get a choice of 32 sets of sound effects and controls (see page E-33/E-34 for a full list) that you can assign to the pads. Once you set the pads to the functions that you want, they are always on hand whenever you need them.

Types of operations available for the pads

Function	Function Numbers	Description
Phrases	00 to 09	Short musical phrases. 00 is the default setting for the pads.
Percussion/ Sound Effects	10 to 29	Percussion and sound effects
Controller	30 to 31	Controls for pitch, vibrato, etc.

To change the pad functions

1. Look at the pad function list printed on the keyboard's console and find the one you want to assign to the pads.
 - Here we will assign set 05, which is PHRASE 6.

2. Press any one of the four pads and the number that identifies the set of functions currently assigned to the pads appears on the display.

SOUND/CONTROL PAD



A


B




C

D

- The number remains on the display for about two seconds.



3. While the function set number is on the display, use the 10-key pad to input the number of the set of functions you want to change to.



- Remember that you have two seconds after pressing the pad to input the first digit. Otherwise, the pad function number will disappear from the display, and you will have to press a pad again to get it back.



The following lists show each of the sounds and controls that can be assigned to the pads. Note that assignment is made in sets of 4. You cannot assign to each pad individually.

Phrases (00 to 09)

The numbers in parentheses are the tone numbers used for each pad.

00 A TIMPANI (047) C BRASS (061) B HARP (046) D COUNTRY FARM (094)	05 A FIFTHLEAD (086) C CELESTA (008) B STRINGS 1 (048) D HONKY-TONK (003)
01 A ATMOSPHERE (099) C COSMIC SOUND (103) B BRIGHTNESS (100) D PEARL DROP (096)	06 A GUNSHOT (127) C DRUM B SYNTH-LEAD1 (080) D METAL LEAD (084)
02 A PIANO (000) C STRINGS (048) B PIANO (000) D TRUMPET (056)	07 A PIANO (000) C PIANO (000) B PIANO (000) D PIANO (000)
03 A FLUTE (073) C ORCHESTRA HIT (055) B PICCOLO (072) D CHOIR (052)	08 A DRUM C DRUM B DRUM D DRUM
04 A ENGLISH HORN (069) C STEEL DRUM (114) B SITAR (104) D WOOD BASS (032)	09 A DRUM C DRUM B DRUM D DRUM

Percussion/Sound Effects (10 to 29)

10 A KICK 1 C HIHAT-CLOSED B SNARE 1 D HIHAT-OPEN	12 A KICK 4 C HIHAT-CLOSED B SNARE 5 D HIHAT-OPEN
11 A KICK 1 C TOM-LOW B SNARE 1 D TOM-HIGH	13 A KICK 4 C TOM-LOW B SNARE 5 D TOM-HIGH

14 A KICK 3 B SNARE 2	C HIHAT-CLOSED D HIHAT-OPEN	22 A CABASA B MARACAS	C WOODBLOCK-HIGH D WOODBLOCK-LOW
15 A KICK 3 B SNARE 2	C TOM-LOW D TOM-HIGH	23 A CUICA-MUTE B CUICA-OPEN	C VIBRASLAP D TAMBOURINE
16 A KICK B SNARE	C HIHAT-CLOSED D HIHAT-OPEN	24 A WHISTLE-SHORT B WHISTLE-LONG	C GUIRO-SHORT D GUIRO-LONG
17 A KICK B SNARE	C TOM-LOW D TOM-HIGH	25 A TRIANGLE-MUTE B TRIANGLE-OPEN	C COWBELL D BELL
18 A RIDE B CRASH	C SPLASH D CHINA	26 A HAND-CLAP B SCRATCH 1	C SCRATCH 2 D SCRATCH 3
19 A KICK 1 B SNARE 1	C SIDE-STICK D HAND-CLAP	27 A STEELDRUM-HIGH B STEELDRUM-LOW	C TAIKO-HIGH D TAIKO-LOW
20 A BONGO-HIGH B BONGO-LOW	C CONGA-HIGH D CONGA-LOW	28 A TIMPANI-LOW B ORCHIT-LOW	C TIMPANI-MID D ORCHIT-MID
21 A TIMBALE-HIGH B TIMBALE-LOW	C AGOGO-HIGH D AGOGO-LOW	29 A APPLAUSE B HELICOPTER	C GUNSHOT D TELEPHONE

Controller (30 to 31)

30 A BEND UP (FAST) B BEND DOWN (FAST)	C MODULATION (SHALLOW) D MODULATION (DEEP)	31 A BEND UP (SLOW) B BEND DOWN (SLOW)	C BEND UP AND DOWN D BEND TREMOLO
---	---	---	--------------------------------------

Notes

- Bend Up/Bend Down produces an effect like the one that is produced by bending the strings of a guitar. The range is two semitones up and down from the original note.
- The bend range for Bend Up/Bend Down is adjustable to either two semitones or three semitones ("To set the bend range" on page E-53).
- Modulation changes the amplitude of vibrato.
- In 28 and 29, the tones will be different from the tone shown above when transposed.
- Use the ACCOMP VOLUME button to control the volume for pads 08 and 09.

■ Assigning rhythms to the Intro, Variation, and Ending Buttons

Normally when you press an Intro, Variation, or Ending button, a corresponding pattern is played to match the main rhythm that you are currently using. Using the procedure described below, however, you can assign any of the 128 rhythms to each


of the Intro, Fill-In, and Ending buttons. When you do, a pattern that matches the preset rhythm sounds when you press the button.

To change the Intro, Fill-In, and Ending button rhythm assignments


1. Press the Intro, Fill-In, or Ending button whose rhythm you want to change and the number that identifies the rhythm currently assigned to the button appears on the display.




- The number remains on the display for about two seconds.



2. While the rhythm number is on the display, use the 10-key pad to input the number of the rhythm you want to change to.



- Remember that you have two seconds after pressing the button to input the first digit. Otherwise, the rhythm number will disappear from the display, and you will have to press the button again to get it back.



- Whenever you change to a different main rhythm, all of above buttons automatically change to the new rhythm.
- You can also change the rhythm assigned to the NORMAL/FILL-IN button. When you do, however, the display for the main rhythm continues to show the main rhythm setting, even though the rhythm you assigned to the NORMAL/FILL-IN button is the one that sounds.

Example: When 000 is set as the main rhythms and you assign 111 to the NORMAL/FILL-IN button.

In this case, pressing the NORMAL/FILL-IN button causes rhythm 111 to sound, but the rhythm display shows 000.

■ Using Magical Presets

Magical Presets let you configure the keyboard to perform a variety of special effects, such as playing a short accompaniment phrase when you press a keyboard key, changing tones each time you press a keyboard key, and much more. There are a total of 128 Magical Presets in memory for instant recall when you need them.

To change the Magical Preset


1. Look at the magical preset list printed on the keyboard's console and find the one you want.
 - Here we will assign Magical Preset 016, which is Melodycomp 1.
2. Press the MAGICAL PRESET button, and the number that identifies the current Magical Preset appears on the display.




- Note that the “•” indicator on the display moves to the far right to indicate the Magical Preset display.



3. Use the 10-key pad to input the number of the Magical Preset you want to change to.



- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed Magical Preset number by 1, while [-] decreases it.
- Be sure to always specify a 3-digit number.
- If you specify a number greater than 127, Magical Preset number 127 is selected automatically.




The keyboard is now assigned the Magical Preset that you specified in the above procedure.

To switch Magical Preset off

Press the MAGICAL PRESET button to switch the function off.



- Note that the “•” indicator on the display moves to the left to indicate that Magical Preset is switched off.



About Magical Presets

Following are detailed explanations of each type of Magical Preset.

Break Beat (000 to 015)

With Break Beat, pressing any of the keys in the range shown below, causes the selected Break Beat phrase to sound. Each phrase is four measures long, and it continues to sound as long as you keep the key depressed. The phrase is played in the key that corresponds to the keyboard key that you press (pressing C plays the phrase in C). Note that you can also control the tempo of the phrase using the TEMPO buttons.



Break Beat Application Examples

- Keep a Break Beat keyboard key depressed and play along with a melody for ad-lib practice with a single chord.
- Press a different Break Beat keyboard key at the point where a progression changes chords and play the chord using the accompaniment keyboard.

Melodycomp (016 to 023)

Melodycomp contains a variety of chord progressions which can be controlled by your phrasing of the melody. If you play a smooth (*legato*) melody line leaving no space between the notes, Melodycomp will play the first chord of the progression behind you. To advance to the next chord, simply lift your hand and start a new legato melody line. In this way, you can control when the chord changes occur by playing the melody legato or leaving gaps.

Example : Greensleeves
 Magical Preset
 Number : 019
 Tone Number : 046



- In general, play in legato without completely removing your fingers from the keyboard.
- Momentarily release all keys where marked with in the score.
- If you want to stop and start again from the beginning, reset the Magical Preset and tone numbers.

Shadow Drum (024 to 027)

With Shadow Drum, pressing a keyboard key plays the percussion sound. As shown in the score below, if you play notes at fixed intervals, it creates the effect of playing along with a drummer.




Free Session (028 to 059)


Free Session gives you a selection of preset chord progressions (see page A-4 for a full list) that you can play along with. Free Session chord changes play automatically, independent of what you play on the keyboard. Use the following procedure to start a Free Session progression.

To start a Free Session progression

1. After selecting the Free Session progression you want to use (see "To change the Magical Preset" on page E-35), press a key on the Free Session accompaniment keyboard to define the key of the progression.



- Pressing one of the keys in the above illustration starts auto-accompaniment play in the key that matches the key you press. You can then use any of the keyboard's keys to play Free Session chords. To select the key of C for example, press the C key.



2. You can also change the rhythm being used with a Free Session progression.

3. To stop play of the Free Session progression, press the START/STOP button.



- Note that you can use ending patterns (see "Improvising with the preset patterns" on page E-21) with Free Session progressions.
- Whenever you play a fill-in pattern during a performance using Free Session, play returns to the first chord of the selected chord progression.

Tone Stack (060 to 099)

Tone Stack brings you additional tones that are separate from the standard preset tones. Note, that you can play auto rhythms with Tone Stack tones, but you cannot use auto-accompaniment.

Key Split (100 to 111)

Key Split splits the keyboard between a number of different tones and sounds.

100 to 103	Sound Effects
104 to 107	Percussion (no sounds produced on the 9 far right keyboard keys)
108 to 111	Bass + Keyboard tones

- You can play auto rhythms with Key Split tones, but you cannot use auto-accompaniment.
- If the key of the keyboard is transposed (see "To transpose the keyboard" on page E-58) while you are using Key Split, one of the keys of the keyboard may play sounds that are from another section of the keyboard. Which key plays a different sound depends upon how much the keyboard is transposed.

Hyperactive (112 to 127)

112 to 115	Each press of a key changes the stereo position
116 to 119	Pressing a single key plays an arpeggio pattern based on the note played. You can use the TEMPO buttons to change the tempo used for the arpeggio.
120 to 123	Each press of a key changes the tone
124 to 127	Pressing a single key automatically adds harmony

- The tone is automatically set to match the Hyperactive effect that is selected.
- You can use the TONE button to select another tone while using Hyperactive. When you do, the initial note is played in accordance with your selection, but arpeggio patterns and harmony notes are played using the initial tones automatically selected by the Hyperactive function.
- You can play auto rhythms with Hyperactive, but you cannot use auto-accompaniment.

■ Using tone buttons with Magical Presets


You can use the TONE button to change tones while you are using Magical Presets.

To change the tone

1. Press the MAGICAL PRESET button.



2. Use the 10-key pad to select the Magical Preset you want to use.



3. Press the TONE button.



4. Use the 10-key pad to input a tone number.



- To change to another Magical Preset, press the MAGICAL PRESET button. To use the Magical Preset that you were using again, press the MAGICAL PRESET button and then select that Magical Preset number again.
 - When you press the TONE button, either the currently selected tone number, the currently selected Magical Preset number, or a number used by the keyboard for internal processing appears on the display. The type of number depends on the type of Magical Preset that you are using.
- *1 When you are using Magical Preset 065, for example, pressing the TONE button displays 047.
- *2 When you are using Magical Preset 104, for example, pressing the TONE button displays 128.
- Selecting one of the 128 preset tones while using Tone Stack (060 to 099) causes the selected preset tone and the Tone Stack tone to sound together.
 - Selecting one of the 128 preset tones while using Key Split (108 to 111) causes the selected preset tone to sound when you play on the high end of the keyboard.
 - If you press the LAYER or SPLIT button while a Magical Preset number is shown on the display, the Magical Preset number is cleared and the display changes to show data for the button you pressed.

■ Using the Registration function

With the Registration function, you can save setups such as tone and rhythm selections, tempo settings, and effect selections for instant recall. You can store up to four set-ups (0 to 3) in registration memory.

To store a set-up


1. First of all, make the following settings and selections:
 - Tone number
 - Rhythm number
 - Tempo
 - Chord type (NORMAL, CASIO CHORD, FINGERED, FULL RANGE CHORD)
 - Accompaniment volume
 - Effects

- Layer on/off
- Split on/off
- Pad function set
- Assignable jack
- MIDI send channel on/off; GM on/off; local control on/off; bend range, auto-accompaniment on/off
- Rhythm settings for the INTRO, NORMAL/FILL-IN, VAR/FILL-IN, and SYNCHRO/ENDING buttons


2. Press the REGISTRATION button twice.




- The REGISTRATION indicator starts to flash.
- Each press of the REGISTRATION button changes the REGISTRATION indicator as shown on the right. Make sure that **r E c** is shown on the display.
- Note that the REGISTRATION button is not operational while a Magical Preset number is displayed or while the Song Memory indicator is lit.



3. Use the 10-key pad to input the number of the registration memory where you want to store your set-up.



- Specify 0, 1, 2, or 3.
- You can also use the 10-key pad's [+] or [-] to change the displayed value.
- Remember that you have five seconds after pressing the REGISTRATION button to input the number. Otherwise, the **r E c** message will disappear from the display, and you will have to press the REGISTRATION button again to get it back.
- Note that if you store a set-up to a memory location that already contains a set-up, the previous set-up is replaced by the new one.



4. After inputting a number, press the REGISTRATION button again to store the set-up in memory.




To recall a setup


1. Press the REGISTRATION button.




- The REGISTRATION indicator lights.
- Each press of the REGISTRATION button changes the REGISTRATION indicator as shown on the right. Make sure that **P L Y** is shown on the display.
- Note that the REGISTRATION button is not operational while a Magical Preset number is displayed or while the Song Memory indicator is lit.



2. Use the 10-key pad to input the number of the registration memory that contains the set-up you want to recall.



- Specify 0, 1, 2, or 3.
- You can also use the 10-key pad's [+] or [-] to change the displayed value.
- Remember that you have five seconds after pressing the REGISTRATION button to input the number. Otherwise, the **PL Y** message will disappear from the display, and you will have to press the REGISTRATION button again to get it back.



Important!

The following occurs whenever you recall a Registration Memory set-up while a rhythm is sounding.


- The currently selected rhythm does not change to the rhythm specified in the recalled Registration Memory set-up.
- If the number of the currently selected rhythm is on the display when you recall a Registration Memory set-up in which the last parameter you input was a rhythm number, the displayed number changes to the rhythm specified in the recalled Registration Memory set-up (though the rhythm itself does not change).
- If the number of the currently selected rhythm is on the display when you recall a Registration Memory set-up in which the last parameter you input was not a rhythm number, the displayed number continues to show the currently selected rhythm (which remains selected).
- All other parameters change to those specified in the Registration Memory set-up.
- After the Registration Memory set-up is recalled, any of the following operations will cause the rhythm to change to the one specified in the recalled Registration Memory set-up: NORMAL/FILL-IN, VAR/FILL-IN, SYNCHRO/ENDING, START/STOP, INTRO.

To switch the Registration function off





The keyboard automatically switches the Registration function off whenever you change any setting already stored in a Registration memory.

■ Assignable jack

As the name suggests, this is an assignable jack to which you can assign a function. Specifically, you can assign pedal functions for an optionally available foot pedal (SP-2 or SP-10).



The following are the functions that can be assigned to the assignable jack.


Function	Display Indicator	Description
Sustain		<ul style="list-style-type: none"> With piano and other attenuating tones, the pedal works like a piano's damper pedal to cause notes to linger. With organ and other sustaining tones, pressing the pedal causes the played note to be held.
Sostenuto		<ul style="list-style-type: none"> This function works similarly to Sustain, but the timing of the effect is different from that used for Sustain. If the pedal is pressed after a note is played (and the keyboard key is still depressed), only that note is sustained.
Soft		<ul style="list-style-type: none"> Softens notes played on the keyboard
Rhythm Start/Stop		<ul style="list-style-type: none"> This function assigns the function of the START/STOP button to the pedal.

To change the assignable jack function

- Press the MIDI button until the message  appears on the display.




- Each press of the MIDI button changes the displayed message in the following sequence.



- Use the 10-key pad's [+] and [-] buttons to change the displayed assignable jack function to the one you want to use.



- Each press of [+] and [-] changes the displayed jack function in the following sequence.



➡: By pressing +

↩: By pressing -


- Remember that you have five seconds after displaying the **UAC** message to input the number. Otherwise, the **UAC** message will disappear from the display, and you will have to press the MIDI button again to get it back.

■ Using the Song Memory

The Song Memory lets you record up to approximately 1,300 notes in memory. You can then play it back and even play along with yourself on the keyboard.

Basic Song Memory operations

The status of the Song Memory changes each time you press the Song Memory button.



Status	Operation
1. Normal	Return here when you are finished using the Song Memory.
2. Playback	Playing back from Song Memory.
3. Record	Recording to Song Memory.

Important!


- Be sure to return to 1. Normal whenever you are not using the Song Memory. Some keyboard operations (such as Magical Presets and Registration Memory) cannot be used while the Song Memory is set to 2. Playback or 3. Record.
- Any time you store something into Song Memory, anything that was previously there is automatically deleted and replaced with the new recording.
- Song Memory contents are retained in memory as long as power is supplied from batteries or an AC outlet. If power is cut off (by dead batteries and unplugging from an AC outlet), everything stored in Song Memory will be deleted.
- If the POWER indicator goes out while recording is in progress, anything recorded up to that point is deleted.

To record to Song Memory



1. First, set up the keyboard to play the tune you want to record.

- Note that you will not be able to record to Song memory while a Magical Preset number (page E-35) is displayed. If Magical Preset number is displayed, press MAGICAL PRESET to switch the Magical Preset function off.

2. Press the SONG MEMORY button twice.



- The SONG MEMORY indicator starts to flash.
- Each press of the SONG MEMORY button changes the SONG MEMORY indicator as shown on the right. Make sure that **[r E c]** is shown on the display.
- After about five seconds, the **[r E c]** message clears from the display, but the SONG MEMORY indicator continues to flash, indicating that the keyboard is still standing by to record.



3. Press the START/STOP button to start recording.



- If you want to record something without using a rhythm pattern, skip this step and continue from step 4.
- The rhythm pattern starts to play after a 4-beat count. Each beat of the count is indicated by the START/STOP indicator.
- Anything you play on the melody keyboard while the 4-beat count is sounding is also recorded in Song Memory.
- To use synchro start, press the SYNCHRO/ENDING button in place of the START/STOP button. Recording and rhythm play will start automatically when you play something on the accompaniment keyboard.
- To start with an intro pattern, press the SYNCHRO/ENDING button and then the INTRO button in place of the START/STOP button. Recording and the intro pattern play will start automatically when you play something on the accompaniment keyboard.
- To start rhythm play part way through a recording, press the SYNCHRO/ENDING button in place of the START/STOP button. Recording will start automatically when you play something on the melody keyboard, and the rhythm will start automatically when you play something on the accompaniment keyboard.

4. Play the song that you want to perform.

- Whenever the Song Memory has less than 100 notes of capacity remaining while you are recording, the Song Memory indicator starts to flash quickly. When memory becomes full, the indicator stops flashing. If you are using auto-accompaniment, it also stops when memory becomes full.

5. After the song is finished, press the START/STOP button to stop the recording operation.




- To end with an ending pattern, press the SYNCHRO/ENDING button. The ending pattern will play and then be recorded and the rhythm pattern will stop automatically.

To play back a song from Song Memory


1. Press the SONG MEMORY button once.



- The SONG MEMORY indicator lights.



- Each press of the SONG MEMORY button changes the SONG MEMORY indicator as shown on the right. Make sure that **[P L Y]** is shown on the display.
- After about five seconds, the **[P L Y]** message clears from the display, but the SONG MEMORY indicator stays lit, indicating that the keyboard is still standing by to play back.



2. Press the START/STOP button to start playback.

START/STOP



- Each beat of the rhythm count is indicated by the START/STOP indicator.
- You can change the volume and rhythm settings while playback is in progress. If the Song Memory tune was recorded along with changes in these settings, the recorded settings will take place where they are recorded, regardless of the manual changes you make during playback.
- You can use the entire keyboard for play along with playback from the Song Memory.
- Playback stops automatically (and the START/STOP indicator stops flashing) when the end of the Song Bank piece is reached.
- You can manually stop playback from the Song Memory at any point by pressing the START/STOP button.

About data recorded in the Song Memory

In addition to the notes you play on the keyboard, the following data is also stored in Song Memory. These operations are also performed whenever you play back from Song Memory.

- Tone numbers
- Rhythm numbers
- Intros
- Endings
- Accompaniment patterns (NORMAL and VARIATION)
- Fill-ins (NORMAL and VARIATION)
- Chord progressions
- Chord play method*1
- Pedal operations
- Split on/off
- Layer on/off
- Pad operations
- Effect types
- Assignable jack settings
- Rhythm numbers assigned to the four auto-accompaniment buttons (INTRO, NORMAL/FILL-IN, VARIATION/FILL-IN, SYNCHRO/ENDING)

*1 CASIO Chord, Fingered, Full Range Chord. If you change the split on/off or Layer on/off setting during a recording, you will not be able to change the chord play method during that recording.

How Touch Response is handled by Song Memory

A song recorded into Song Memory includes Touch Response data. Note, however, that the Touch Response applied for playback is in accordance with the Touch Response sensitivity settings (see "To set the touch sensitivity" on page E-59) in effect on the keyboard.

- Whenever you change Touch Response sensitivity (page E-59) while playing back from the Song Memory, that setting is not immediately applied to the playback of the song that is playing. It will be applied starting from playback of the next song. You should note, however, that the new Touch Response sensitivity setting is immediately applied to keyboard play, even during playback of the current song.

Important!

Transpose, Tuning, Tempo, Split point are not stored into Song Memory. Whenever you change these settings while playing back from the Song Memory, these settings are not immediately applied to the playback of the song that is playing. It will be applied starting from playback of the next song. You should note, however, that the new settings are immediately applied to keyboard play, even during playback of the current song.

■ What is MIDI?

“MIDI” stands for Musical Instrument Digital Interface, which is a worldwide standard for the exchange of digital signals produced by electronic musical instruments and devices. MIDI lets you easily exchange data with other MIDI devices, regardless of maker or model.

■ What the MIDI Mode allows you to do

The MIDI mode of this keyboard makes it possible for you to send and receive a variety of digital data.

Send

- You can connect to a MIDI device to sound the notes you play on the keyboard. This provides you with the means of playing two or more instruments at once, for richer sound and expanded versatility.
- You can connect to a sound module*¹ to provide you with a wider selection of tones.
- You can connect to a commercially available MIDI sequencer*² to record your keyboard play.
- Each part of this keyboard’s rhythm and auto-accompaniment patterns can be output over separate channels.

Receive

- You can connect to a MIDI device and sound notes played on the device using the keyboard’s tones.
- You can connect to a commercially available MIDI sequencer*² to play back on your keyboard. With this configuration, you can simultaneously play multiple parts*³ as they are received.

*1 A sound source that can be controlled by an external MIDI device.

*2 An external module that performs recording capabilities. Using a sequencer that can store data on disks or cards provides you with virtually unlimited storage for your recordings.

*3 For the send and receive operations, channels are allocated as follows.


- Channels 1 to 9, 16: Tones (see page E-28 and E-29 for information on Split and Layer).
- Channels 10 to 14: Auto-accompaniment parts
- Channel 15: Pad data

■ About the MIDI terminals

MIDI terminals are equipped to provide a place to connect special MIDI cables that carry digital signals between MIDI devices. The CTK-650 features MIDI IN and MIDI OUT terminals.


MIDI IN

- This is an input terminal that connects to the MIDI OUT or MIDI THRU terminal of another device. Data passes from the MIDI OUT terminal of the sending unit to the MIDI IN terminal of the receiving unit.



MIDI OUT


- This is an output terminal that connects to the MIDI IN terminal of another device. Data passes from the MIDI OUT terminal of the sending unit to the MIDI IN terminal of the receiving unit.




■ What is a MIDI channel?

MIDI channels range from 1 through 16, and you can think of them as being similar to the channels on your television. Just as your TV has to be tuned into channel 3 to receive broadcasts on that channel, a receiving MIDI device cannot receive MIDI channel 3 data unless it is set properly to channel 3.

Channel 3 broadcast



Receivable on Channel 3





To set the basic channel


1. Press the MIDI button until the message **cH** appears on the display.



- Each press of the MIDI button changes the displayed message in the following sequence.



2. Use the 10-key pad to input the number of the channel that you want to set as the basic channel.



- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed channel number by 1, while [-] decreases it.
- Be sure to always specify a 2-digit number.
- Remember that you have five seconds after displaying the **cH** message to input the number. Otherwise, the **cH** message will disappear from the display, and you will have to press the MIDI button again to get it back.

MIDI Send Channel Allocation

MIDI Channel	1	2	3	4
Application	Real-time accompaniment			
Normal	Keyboard play			
Layered	Base tone	Layered tone		
Split	High end		Low end tone	
Layered & Split	High end base tone	High end layered tone	Low end base tone	Low end layered tone

MIDI Channel	5	6	7	8
Application	Song Memory Playback			
Normal	Keyboard play			
Layered	Base tone	Layered tone		
Split	High end		Low end tone	
Layered & Split	High end base tone	High end layered tone	Low end base tone	Low end layered tone

MIDI Channel	9	10	11	12
Application		Auto-accompaniment		
Normal		Rhythm	Bass	Chord 1
Layered		Rhythm	Bass	Chord 1
Split		Rhythm	Bass	Chord 1
Layered & Split		Rhythm	Bass	Chord 1

MIDI Channel	13	14	15	16
Application	Auto-accompaniment		Pad	
Normal	Chord 2	Chord 3	Pad	
Layered	Chord 2	Chord 3	Pad	
Split	Chord 2	Chord 3	Pad	
Layered & Split	Chord 2	Chord 3	Pad	

Ranges

When notes that are higher or lower than the range covered by this keyboard are received, it automatically selects the same note in the nearest octave covered, and sounds the note using the appropriate tone type. For full details on the ranges of notes that can be sounded, see the Note Table on page A-6.

While using Magical Presets 108 through 111 (Key Split), only performances within the split high range is sent as MIDI data.

Pedal effects

The effects produced when using separately available sustain, sostenuto and soft pedals can be sent and received over MIDI.

Tone type changes

The tone numbers from 000 through 127 used by this keyboard correspond to the numbers defined by General MIDI standards (page E-51). This means that if tone number 8 is selected on the unit sending data to this keyboard, tone number 008 (Celesta) is selected by this keyboard for the received data. This selection is performed regardless of what tone number 008 is on the sending unit.

When this keyboard sends tone data (002 STUDIO PIANO, for example), it includes data that states “select tone number 002,” and the receiving unit selects tone 002. This selection is performed regardless of what tone number 002 is on the receiving unit.

- When this keyboard receives data, MIDI channels 1 through 8 is applies in accordance with this keyboard's sensitivity setting $\boxed{r \cdot 0}$ to $\boxed{r \cdot 2}$, page E-59.

Touch Response

- Even when Touch Response is switched off, this unit sends data that indicates the pressure used to operate the keyboard keys.
- When this unit receives data, it applies Touch Response data in accordance with whether or not its own Touch Response function is switched on or off.

Volume balance between channels

Channels 1 through 9, 15 and 16

You cannot make changes in volumes using this keyboard. Changes are made only if they are received from a connected MIDI device.

Channels 10 through 14

You can change the volume settings of these channels using this keyboard's Accompaniment Volume setting. Changes are also made when they are received from a connected MIDI device*.

* Control change 7

Modulation depth , stereo position (pan), effect volume (effect send)

- You cannot set modulation volume, stereo position, and effect volume using this unit. Changes are made only if they are received from a connected MIDI device.
- If a program change is received from a connected device, this keyboard returns to its initial settings.
- See the MIDI Implementation chart at the back of this manual for details.

Notes

- With effect number 03 (CHORUS), the stereo position is always located in the center, and any external changes in this setting are ignored.
- With effect number 07 (ENHANCER) and effect number 09 (LOUDNESS), the effect volume is fixed at maximum, and any external changes in this setting are ignored.
- MIDI Channel 10 cannot receive an effect send command.

Sound/Control pads

The sound and sound number is sent when a pad is pressed, except for pad functions 30 and 31 (Bend Up, Bend Down). When receiving data, you can use the pads 30 and 31 to apply their effects to the sounds being received.

■ Song Memory and demo tunes

You cannot send Song Memory and demo tune playback as MIDI data. Also, you cannot save MIDI data in this keyboard's Song Memory.

■ General MIDI

The General MIDI System Level 1 (popularly known as General MIDI) was published in 1991 to define a certain class of MIDI synthesizer modules that are more standardized and easier to use. Note that the numbers of the tones of this keyboard conform with General MIDI specifications, but in other aspects it does not conform. This means that you may experience some compatibility problems when connecting this keyboard to a General MIDI device.

Use the following operation to switch the General MIDI capabilities of this keyboard on and off. When this keyboard receives data with General MIDI on, some tones* of the keyboard are raised one octave, in accordance with General MIDI specifications.



* Tone number 32~39, 43, 67, 70.

To switch General MIDI on and off

1. Press the MIDI button until the message **G o n** (General MIDI on) appears on the display.



- Each press of the MIDI button changes the displayed message in the following sequence.




2. Use the 10-key pad's [+] and [-] buttons to switch General MIDI on and off.



- Pressing [+] switches General MIDI on, while [-] switches it off.
- Remember that you have five seconds after displaying the **G o n** / **o n** or **a f f** message to make your selection. Otherwise, the message will disappear from the display, and you will have to press the MIDI button again to get it back.

■ Local control settings


You can use local control to specify whether keyboard, sound control pad, or pedal operations should be output through MIDI OUT only, or whether they should be applied to the local sound source (the instrument you are playing).



Local control is normally switched on, and it is always switched on automatically whenever you switch the power of the keyboard on or whenever you play a demo tune. When local control is switched off, playing the keyboard and operating the pedal does not affect the keyboard itself, but only affects the connected MIDI device.

To switch Local Control on and off

1. Press the MIDI button until the message **L on** (Local Control on) appears on the display.
 - Each press of the MIDI button changes the displayed message in the following sequence.



2. Use the 10-key pad's [+] and [-] buttons to switch Local Control on and off.



- Remember that you have five seconds after displaying the **L on** / **o n** or **o f f** message to make your selection. Otherwise, the message will disappear from the display, and you will have to press the MIDI button again to get it back.

Bend range settings


This setting defines the amount that tones are changed by the pitch bend controller. You can select between two different settings. Note that the pitch bend controller for this keyboard is controlled by pad function settings 30 and 31 (see “Controller (30 to 31)” on page E-34). The setting you make here determines the pitch bend amount applied when you press a pad set with these functions.

To set the bend range

1. Press the MIDI button until the message **bnd** appears on the display.




- Each press of the MIDI button changes the displayed message in the following sequence.



- After a short while, the current bend range setting (2 or 3) appears on the display.

2. Use the 10-key pad to input 2 (two semitones) or 3 (three semitones) to specify the bend range.



- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed number, while [-] decreases it.
- Remember that you have five seconds after displaying the **bnd** message to make your selection. Otherwise, the message will disappear from the display, and you will have to press the MIDI button again to get it back.
- Auto-accompaniment patterns such as rhythm number 110 (ENKA) that include pitch bend operations were programmed using a bend range of 2. If you play these rhythms using a bend range of 3, the resulting rhythm will sound strange.

Accompaniment data

With this setting, you can specify whether or not the rhythm, bass, and chord data for the auto-accompaniment played on the keyboard should be output through the MIDI OUT terminal.


To switch accompaniment data output on and off

1. Press the MIDI button until the message **ACP** appears on the display.




- Each press of the MIDI button changes the displayed message in the following sequence.





- After a short while, the current (send) / (do not send) setting appears on the display.

2. Use the 10-key pad's [+] and [-] buttons to switch accompaniment data output on and off.



- Remember that you have five seconds after displaying the message to make your setting. Otherwise, the message will disappear from the display, and you will have to press the MIDI button again to get it back.

Accompaniment data is sent using the following MIDI OUT channels.

Channel	10	11	12	13	14
Part	Rhythm (percussion)*	Bass	Chord 1	Chord 2	Chord 3

- * Percussion instrument types and MIDI note numbers conform with General MIDI specifications. The following shows the relationship between percussion numbers and names.

General MIDI Percussion Map (Channel 10) :

MIDI Key	Drum Sound	MIDI Key	Drum Sound	MIDI Key	Drum Sound
35	Acoustic Bass Drum	41	Low Floor Tom	47	Low-Mid Tom
36	Bass Drum 1	42	Closed Hi Hat	48	Hi Mid Tom
37	Side Stick	43	High Floor Tom	49	Crash Cymbal 1
38	Acoustic Snare	44	Pedal Hi-Hat	50	High Tom
39	Hand Clap	45	Low Tom	51	Ride Cymbal 1
40	Electric Snare	46	Open Hi-Hat	52	Chinese Cymbal

MIDI Key	Drum Sound	MIDI Key	Drum Sound	MIDI Key	Drum Sound
53	Ride Bell	63	Open Hi Conga	73	Shot Guiro
54	Tambourine	64	Low Conga	74	Long Guiro
55	Splash Cymbal	65	High Timbale	75	Claves
56	Cowbell	66	Low Timbale	76	Hi Wood Block
57	Crash Cymbal 2	67	High Agogo	77	Low Wood Block
58	Vibraslap	68	Low Agogo	78	Mute Cuica
59	Ride Cymbal 2	69	Cabasa	79	Open Cuica
60	Hi Bongo	70	Maracas	80	Mute Triangle
61	Low Bongo	71	Short Whistle	81	Open Triangle
62	Mute Hi Conga	72	Long Whistle		

■ Assignable jack data

Though this setting is made using the MIDI key, it is actually not part of MIDI data. For details on making this setting, see “Assignable jack” on page E-41.

■ Specifying a tone for each receive channel


Individual tones can be specified for each of the 16 channels when receiving data from another MIDI device. This means that you can connect to a commercially available MIDI multi-track sequencer, and play up to 16 tones simultaneously. Remember, however, that the maximum polyphony for this keyboard is 32 notes.




To specify a tone for a receive channel


1. Press the MIDI button until the message **c 0 1** appears on the display.




- Each press of the MIDI button changes the displayed message in the following sequence.



- Here, we selected channel 1 , but you could also select any of the 16 channels  through .
- After a short while, the number of the tone currently assigned to the channel you selected appears on the display.



2. Use the 10-key pad to input the 3-digit number that identifies the tone you want to select.



- Use the numeric buttons to input a 3-digit number.
- You can also use the [+] and [-] buttons. Pressing [+] increases the displayed tone number by 1, while [-] decreases it.
- Be sure to always specify a 3-digit number.
- If you specify a number greater than 127, tone number 127 is selected automatically.
- If you discover a mistake before you input the third digit, press the MIDI button to return to the previously set tone number.
- Channel 10, which is reserved for percussion instruments under General MIDI standards, has eight presets, from 0 to 7. This keyboard also reserves channel 10 for percussion instruments, but you can select only one of the eight presets.
- This keyboard cannot shut off receive channels. If you do not want to receive a channel, switch that channel off on the sending unit.
- Magical Preset uses MIDI channels 1 through 4. If you are using Tone Stack, for example, these tones are combined by up to four different tone and assigned to MIDI channels 1 through 4.

MIDI Receive Channel Allocation

MIDI Channel	1	2	3	4
Application				
Normal				
Layered	Base tone	Layered tone		
Split	High end		Low end tone	
Layered & Split	High end base tone	High end layered tone	Low end base tone	Low end layered tone

MIDI Channel	5	6	7	8	9	10	11	12	13	14	15	16
Application						Auto-accompaniment						
Normal						Rhythm	Bass	Chord 1	Chord 2	Chord 3		
Layered						Rhythm	Bass	Chord 1	Chord 2	Chord 3		
Split						Rhythm	Bass	Chord 1	Chord 2	Chord 3		
Layered & Split						Rhythm	Bass	Chord 1	Chord 2	Chord 3		

Part 5 Other Settings



This part of the manual details other general settings.

■ To tune the keyboard


1. Press the TRANSPOSE/TUNE button until the message **tUn** appears on the display.




- Each press of the TRANSPOSE/TUNE button changes the display contents in the following sequence.



2. Use the 10-key pad's [+] and [-] buttons to tune the keyboard.



- Each press of the [+] and [-] buttons changes the setting in the following sequence.
- Holding down either button changes the tuning at high speed.
- Remember that you have five seconds after displaying the **tUn** display to tune the keyboard. Otherwise, the message will disappear from the display, and you will have to press the TRANSPOSE/TUNE button again to get it back.
- Pressing the [+] and [-] buttons at the same time automatically sets the tuning to 00.



- ◆ : Each time you press +
- ◇ : Each time you press -

Notes



- You can tune the keyboard within the range of ± 50 cents (101 levels). 100 cents is equivalent to one semitone.
- Switching power on or playing a demo tune automatically sets the keyboard tuning to 00.
- You can change the tuning of the keyboard when recording to or playing back from the Song Memory. Note however, that keyboard tuning data is not stored in Song Memory.

■ To transpose the keyboard


1. Press the TRANSPOSE/TUNE button until the message **trn** appears on the display.



- Each press of the TRANSPOSE/TUNE button changes the display contents in the following sequence.



2. Use the 10-key pad's [+] and [-] buttons to select a key.



- Each press of the [+] and [-] buttons changes the key of the keyboard in the following sequence.

Key : F# G A^b A B^b B C C# D E^b E F

Display: - 6 - 5 - 4 - 3 - 2 - 1 0 1 2 3 4 5

➡ : Each time you press +

⬅ : Each time you press -

- Holding down either button changes the tuning at high speed.
- You can also specify 0 through 5 by pressing the corresponding 10-key pad button.
- Pressing the [+] and [-] buttons at the same time automatically sets the key of C (0).
- Remember that you have five seconds after displaying the **trn** display to tune the keyboard. Otherwise, the message will disappear from the display, and you will have to press the TRANSPOSE/TUNE button again to get it back.

Important

- The above operation also causes pad sounds to be transposed. Note, however, that some tones do not sound correct after being transposed. Because of this, the keyboard automatically substitutes a different tone to the pad.
- Each of the 128 preset tones has a specific range in which it can sound (see the Note Table on page A-6). If a transpose operation causes a note to exceed its upper or lower range, the same note in the nearest upper or lower octave is used instead.


■ To set the touch sensitivity

1. Press the TOUCH RESPONSE button.


TOUCH RESPONSE




- When you do, the current Touch Response sensitivity setting appears on the display.
- : A strong sound is produced even when you press the keys lightly.
- : Standard sensitivity
- : A medium-level sound is produced when you press the keys strongly.
- : Touch Response off.



2. Use the 10-key pad to input the 1-digit number that identifies the touch sensitivity you want to use.



- Inputting 0 sets , inputting 1 sets , any other input sets .
- You can also use the [+] and [-] buttons. Each press of these buttons changes the setting in the following sequence.



➡ : Each time you press +

⬅ : Each time you press -

Part 6 Technical Reference

■ Troubleshooting

Be sure to check the following table whenever you experience problems with keyboard operation.

Problem	Possible Causes	Action
No sound when playing the keyboard.	<ol style="list-style-type: none"> 1. Power supply problem. 2. VOLUME setting is too low. 3. Headphones are plugged in. 4. You are attempting to play normally on the accompaniment keyboard while CASIO CHORD or FINGERED is selected. 5. Magical Presets 104 through 107 are selected. 6. MIDI Local Control is off. 7. Command from external MIDI device has set the volume of channel 1 to zero. 	<ol style="list-style-type: none"> 1. Connect AC adaptor correctly and make sure that batteries are loaded with the positive (+) and negative (-) poles facing correctly. 2. Move the VOLUME slider more towards the maximum setting. 3. Unplug the headphones. 4. Enter the NORMAL mode (all mode indicators unlit). 5. With these Magical Presets, the far right nine keys normally do not sound. 6. Switch MIDI Local control on. 7. Use the external MIDI device to adjust the volume of channel 1.
Rhythm and auto-accompaniment do not play.	Accompaniment volume is set to 000.	Use the ACCOMP VOLUME button to raise the volume of the accompaniment.
Following symptoms occur when using batteries. <ul style="list-style-type: none"> • Dim power supply indicator • Abnormally low speaker/headphone volume • Distortion of sound output • A totally different tone may sound • Abnormal rhythm pattern and demo tune play • Continued sound output even after you release a button • Occasional interruption of sound when playing at high volumes • Sudden power failure when playing at high volumes 	Low battery power.	Replace the batteries with new ones.
Rhythm sounds, auto-accompaniment sounds, and bass tones (tone numbers 032 to 039) sound distorted.	Effect number 1-9 (EQ Loudness) is being used while the volume is set to a high level.	Lower the volume setting. Change to another effect or switch off effects completely.

■ Care of your keyboard

Avoid heat, humidity or direct sunlight.

Do not overexpose the unit to direct sunlight, or place near an air conditioner, or in any extremely hot place.

Take care not to drop the unit and avoid strong impact.

Strong impact may cause malfunctions. When carrying or transporting the unit, protect the keyboard and switches with soft cloth or other material.

Keep the unit free of liquids, dust, etc.

Do not allow foreign matter to get between the keys, especially metallic objects such as hairpins, sewing needles or coins. Also, do not let the unit get wet.

Never attempt to modify any parts of the unit.

The unit is a precision instrument, made of electronic parts. Any modification of, or tampering with inner parts may cause malfunction.

Do not use lacquer, thinner or similar chemicals for cleaning.


Clean the keyboard with a soft cloth dampened in a weak solution of water and a neutral detergent. (Soak the cloth in the solution and squeeze until it is almost dry.)

■ Specifications

Model:	CTK-650			
Keyboard:	61 standard-size keys; 5 octaves; Touch Response (can be switched on and off, sensitivity; 3 sets)			
Tones:	128 presets			
Polyphony:	32 - note (max.)			
Magical preset:	BREAK BEAT	16	MELODYCOMP	8
	SHADOW DRUM	4	FREE SESSION	32
	TONE STACK	40	KEY SPLIT	12
	HYPERACTIVE	16		
Auto-accompaniment:	Rhythm patterns	128presets		
	Tempo	Adjustable (40 ~ 255)		
	Chords	Three systems: CASIO CHORD, FINGERED, FULL-RANGE CHORD		
	Other	Variation pattern, fill-in pattern, intro/ending pattern for each rhythm		
Song memory:				
song:	one			
System:	Real-time recording			
Memory capacity:	Up to 1.300 notes			
Registration memory:	4 setups			
Contents:	Tone number, rhythm number, tempo, accompaniment volume, chord type (NORMAL,			

	CASIO CHORD, FINGERED, FULL RANGE CHORD), effects, layer on/off, split on/off, pad function set, assignable jack, MIDI sent channel on/off; GM on/off; local control on/off; bend range, auto-accompaniment on/off, rhythm settings for the INTRO, NORMAL/FILL-IN, VAR/FILL-IN, and SYNCHRO/ENDING buttons	
Sound control pads:	Phrases	10
	Drums	10
	SE/PERCUSSION	10
	Controller	2
Digital Effects:	REVERB 1, REVERB 2, REVERB 3, CHORUS, TREMOLO, PHASE SHIFTER, ORGAN SP, ENHANCER, FLANGER, EQ LOUDNESS	
Auto-play tunes:	3 tunes	
Other Functions:	Transpose (G~C~F#:half-note) Tuning Adjustable A4 = 440Hz 100cents increments Volume control (Main/Accompaniment)	
Speakers:	12 cm diameter x 2 (Output: 2W+2W)	
I/O Terminals:	Power Supply	9V DC jack
	Headphones	Stereo mini jack
	[output impedance: 100 Ω , output voltage: 4.5V (RMS) MAX],	
	Assignable jack	Standard jack
	MIDI	IN, OUT
Power Supply:	3-way AC/DC power sources;	
	Batteries	Six D-size
	Battery life	approximately 5 hours on R20P (SUM-1) manganese batteries
	AC	Required optional AD-5 AC adaptor
	Car battery	Required optional CA-5 car adaptor
Auto power off:	Approximately 6 minutes after the last operation	
Power consumption:	7.7W	
Dimensions:	942 x 367 x 135 mm (31 7/16" x 14 1/2" x 4 3/8")	
Weight:	5.2 kg (11.7 lbs) excluding batteries	
Accessory:	Score stand	

* Designs and specifications are subject to change without notice.



Part 7 Appendix

Fingering Chord Charts

Chord Type Root	M	m	7	m7
C				
C#/(Db)				
D				
(D#)/Eb				
E				
F				
F#/(Gb)				
G				
(G#)/Ab				
A				
(A#)/Bb				
B				

Chord Type Root	M7	m7-5	dim	aug	sus4
C					
C#/(Db)					
D					
(D#)/Eb					
E					
F					
F#/(Gb)					
G					
(G#)/Ab					
A					
(A#)/Bb					
B					

Chord Type Root	7sus4	m add9	mM7	7 ⁻⁵	add9
C					
C#/(D ^b)					
D					
(D#)/E ^b					
E					
F					
F#/(G ^b)					
G					
(G#)/A ^b					
A					
(A#)/B ^b					
B					

■ Melodycomp Chord Charts

No.	Chord Chart								
16	CM7	Dm7	CM7	G7sus4	FM7	Em7	Dm7	F / G	
17	CM7	Am7	Dm	G7sus4	CM7	Am7	Dm9	G7sus4	
18	Dm	Am/C	B ^b M7	Gm7	Dm	Am/C	B ^b M7	Gm7	Am7
19	F	C	Dm	A	F	C	Dm	A	D
20	Am	G/A	CM7	FM7	B ^b M7	E ^b M7	Dsus4	E7	Am
21	Am9	Bm9	GM7	Asus4	A	Am9	D6	B ^b M7	A
22	CM7	FM7	D/F [‡]	G	E/G [‡]	Am	Am/F [‡]	B	Em7
	Am7	Am	Gsus4	CM7					
23	Am	F	Gsus4	Em	F	Dm	Em	Am	

■ Free Session Chord Progression Charts: Key of C

No.	Chord Chart									
28	C	z	z	z	F	z	C	z	G	
	F	C	z							
29	C	z	z	z	F	z	C	z	G	
	G	C	z							
30	C	Am	Dm	G7						
31	C	A7	Dm7	G7						
32	C	D7	Dm7	G7						
33	C	C7	F	Fm						
34	C	Am	F	Dm						
35	C	Em	F	G7sus4						
36	C	G	Am	F						

No.	Chord Chart									
37	F	Em	Dm	C						
38	C	G	Am	Em	F	C	F	G7		
39	C	x	Am	x	Dm	x	G7sus4	G		
40	C	x	x	x	Dm7	x	C	x		
41	C	x	G	x	Dm	x	F	G7sus4		
42	Am	C	Bm7 ⁻⁵	E7						
43	Am	F	Bm7 ⁻⁵	E7						
44	Am	F	Dm7	E7						
45	Am	G	F	E7						
46	Am	G	F	x						
47	Am	C	D	Dm						
48	Am	G	D	E7						
49	Am	x	G	x	F	x	Dm7	G7sus4		
50	F	G7	Em	Am						
51	F	G	Am	x						
52	C	E ^b 7	Dm7	G7						
53	C	B ^b	F	C						
54	C	G	Am	F	C	G	F	C		
55	C	Dm7	C	Dm7	C7	F	Em7	G7sus4		
56	C	x	F	x	A ^b	x	B ^b	G7sus4		
57	C	C7	F	F ^{dim}	C	A7	D7	G7		
58	C	x	E ^b	x	C	x	A ^b	G7sus4		
59	C	x	B ^b	x	C	x	D ^b	x		

■ Note Table


Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type
000	32	A	010	16	B	020	32	B	030	32	B
001	32	A	011	32	B	021	32	B	031	32	C
002	16	A	012	32	B	022	32	B	032	32	D
003	16	A	013	32	B	023	32	B	033	32	D
004	32	B	014	32	B	024	32	B	034	32	D
005	32	B	015	32	B	025	32	B	035	32	D
006	32	B	016	16	B	026	32	B	036	32	D
007	32	B	017	16	B	027	32	B	037	32	D
008	32	B	018	16	B	028	32	B	038	32	D
009	32	B	019	16	B	029	32	B	039	32	D

Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type
040	32	B	050	16	B	060	32	B	070	32	E
041	32	B	051	32	B	061	32	B	071	32	B
042	32	B	052	32	B	062	16	B	072	32	F
043	32	E	053	16	B	063	32	B	073	32	B
044	32	B	054	32	B	064	32	B	074	32	B
045	32	B	055	32	B	065	32	B	075	32	B
046	32	B	056	32	B	066	32	B	076	32	B
047	32	B	057	32	B	067	32	D	077	32	B
048	32	B	058	32	E	068	32	B	078	32	B
049	32	B	059	32	B	069	32	B	079	32	B

Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type	Tone number	Maximum polyphony	Range type
080	16	B	090	16	B	100	16	B	110	32	B
081	16	B	091	16	B	101	16	B	111	32	B
082	16	B	092	16	B	102	16	B	112	32	B
083	16	B	093	16	B	103	16	B	113	32	B
084	16	B	094	16	B	104	32	B	114	16	B
085	16	B	095	16	B	105	32	B	*115	32	B
086	16	B	096	16	B	106	32	B	*116	32	G
087	16	B	097	16	B	107	32	B	*117	32	B
088	16	B	098	16	B	108	32	B	*118	16	B
089	16	B	099	16	B	109	32	B	*119	32	B

Tone number	Maximum polyphony	Range type
*120	32	B
121	32	B
*122	16	B
*123	32	B
*124	32	B
*125	32	B
*126	16	B
*127	32	B

* Tones without scale



Range type	C0	C1	C2	C3	C4	C5	C6	C7	C8	C9	G9
A (Acoustic piano type)											
B (Standard type)											
C (031 GUITAR HARMONICS only)											
D (Low range instrument type 1)											
E (Low range instrument type 2)											
F (072 PICCOLO only)											
G (116 TAIKO only)											














a Range of keyboard play



b Playable range (Transpose, When receiving MIDI data)



c Range in which same note is played in nearest octave as a result of transpose and MIDI data receive operation (Transpose, When receiving MIDI data)



Model **CTK-650**

MIDI Implementation Chart

Version: 1.0

Function ...	Transmitted	Recognized	Remarks
Basic Channel Default Changed	1 1-16	1-16 1-16	
Mode Default Messages Altered	Mode 3 X *****	Mode 3 X *****	
Note Number: True voice	36 - 96 *****	0-127 36 - 96	See Note table on page A-6.
Velocity Note ON Note OFF	O 9nH v = 1-127 X 9nH v = 0	O 9nH v = 1-127 X 9nH v = 0, 8n v = XX	XX = no relation
After Touch Key's Ch's	X X	X X	
Pitch Bender	X	O	
Control 01 07 10 64* 66* 67* 91	X X X O O O X	O O O O O O O	Modulation Volume PAN Sustain Sostenuto Soft Effect send
Change			

Program Change:	True #	O 0-127 *****	O 0-127 *****	
System Exclusive		X	X	
System Common	: Song Pos : Song Sel : Tune	X X X	X X X	
System Real Time	: Clock : Commands	O O	X X	
Aux Messages	: Local ON/OFF : All notes OFF : Active Sense : Reset	X X X X	X X X X	
Remarks	* Data is sent for the currently selected assignable jack function.			

Mode 1 : OMNI ON, POLY
Mode 3 : OMNI OFF, POLY

Mode 2 : OMNI ON, MONO
Mode 4 : OMNI OFF, MONO

O : Yes
X : No

CASIO®

CASIO COMPUTER CO., LTD.

6-1, Nishi-Shinjuku 2-chome
Shinjuku-ku, Tokyo 163-02, Japan